

Centronic Plus Remote: Easy Control EC54###a PLUS Turning OFF - (Delete Memo / 24Hr timer function)

START

Press and hold stop button on remote

After 3 seconds LED Ring will light up GREEN

Keep stop button held for a further 3 seconds

After 3 seconds LED Ring will light up RED.



Motor 2 x CLICK

Keep stop button held for a further 3 seconds

END

Motor 2 x CLICK

After 3 seconds LED Ring will flash RED. Then release stop button



• Using the EC541a / 548a / 5416a remote control only